Printer Connector J1	DB25 Parallel Cable		
A	Reserved		Pin #
B	115VAC	Aircraft pwr	
C	Reserved		
D	115VAC Neutral	Aircraft pwr	
E	5VDC	Lighting Pwr	
F	N/C		
G	Reserved		
H	Reserved		
J	Reserved		
K	Logic Ground		?
L	Reserved		
M	Reserved		
N	Reserved		
P	Reserved		
Q	Reserved		
R	Reserved		
S	Reserved		
T	Reserved		
U	Signal Ground		18-25
V	Reserved		
W	Reserved		
X	Reserved		
Y	Reserved		
Z	Reserved		
a	Reserved		
b	Reserved		
c	0VDC	Lighting Pwr	
d	Chassis Ground	Ground	
e	Reserved		
f	Reserved		
g	Ground	Ground	
h	Reserved		
i	Reserved		
j	Data 8		9
k	Ground	Ground	
m	-ACK		10
n	Ground	Ground	
p	Ground	Ground	
q	+Busy		11
r	-Strobe		1
s	Reserved		
t	Data 7		8
u	Data 6		7
v	Data 5		6
w	Reserved		
x	Data 4		5
y	Data 3		4
z	Data 2		3
AA	Data 1		2
BB	Ground	Ground	
CC	Paper Out		12
DD	Ground	Ground	
EE	Ground	Ground	
FF	Ground	Ground	
GG	Ground	Ground	
HH	Ground	Ground	
JJ	Ground	Ground	
KK	Ground	Ground	
LL	Reserved		
MM	Reserved		
NN	-Error		15
PP	Select		17

What's this? (at row K)

Not used? (at N/C? row)

Conn J1	DB25 Printer cable	
r	Strobe	1
AA	Data bit 0	2
z	Data bit 1	3
y	Data bit 2	4
x	Data bit 3	5
v	Data bit 4	6
u	Data bit 5	7
t	Data bit 6	8
j	Data bit 7	9
m	Acknowledge	10
q	Busy	11
CC	Paper out	12
PP	Select	13
N/C	Autofeed	14
NN	Error	15
N/C	Reset	16
N/C?	Select	17
U	Signal ground	18
U	Signal ground	19
U	Signal ground	20
U	Signal ground	21
U	Signal ground	22
U	Signal ground	23
U	Signal ground	24
U	Signal ground	25
d	Shield	Cover